

9.Heater kit : HHC10W

1) Purpose

Heat an engine room, which facilitates the smooth start of the engine even in areas where the temperature is low.

2) Specification

| Item | | Standard specification | Specification for cold region |
|-----------------------------|---------------|---------------------------|---|
| Minimum ambient temperature | | 23°F (-5°C) | 5°F (-15°C) |
| Coolant | Type | Cogeneration coolant L201 | |
| | Concentration | 50% | 60% (coolant change) |
| Drain heater | | Not provided | 250W×2 (under the generator) |
| Block heater | | Not provided | 200W×1 (In the middle of the coolant piping inside the unit) |

3) Circuit diagram

